XPERIA 10vi **SOG14**

Quick Start Guide

 Always update the software to the most recent one. For details on how to update the software, refer to *取扱説明書 詳細版 (Full instruction manual)" (Japanese).

• In this manual, "Xperia 10 VI" is usually referred to as "the product"

or "main unit". In this manual, "Quick Start Guide" (this manual) and "取扱説明 書 詳細版 (Full instruction manual)" (Japanese) are collectively

In this manual, "microSD™ memory card (commercially available)", "microSDHC™ memory card (commercially available)" and "microSDHC™ memory card (commercially available)" are abbreviated as "microSD memory card".

· Company names and product names referred to in this manual are trademarks or registered trademarks of respective companies. The TM and ® marks may be omitted in this

referred to as "Instruction Manual".

When using the product

Before you start using the product, make sure to read the "Safety Precautions (Observe Strictly)" to ensure correct use.

Before you assume that the product is malfunctioning, refer to "故障とお考えになる前に (Check here first)" in "取扱説明書 詳細 版 (Full Instruction Manual)" (Japanese). Communication is not possible even inside of the service area

in places where the signal does not reach (e.g. tunnels and basements). Also, communication is sometimes not possible in poor signal reception areas. Communication is sometimes interrupted if you move into poor signal reception area during

· Since the product uses radio waves, the possibility of communication intercepts by third parties cannot be eliminated. (Though 5G/LTE/WiMAX 2+/GSM/UMTS system has highly secure confidential communication features.)

For connecting to the emergency call acceptance organization, only VoLTE (LTE network) can be used.

Since the product is a radio station under the Radio Law, you may be asked to temporarily submit the product for inspection in accordance with the Radio Law.

· The IMEI information of the product is automatically sent to your carrier for maintenance and monitoring operational status of your mobile phone.

· Before you start using the product overseas, check the relevant laws and regulations of the country/region you visit The Company is not liable for any damages or lost income arising from earthquakes, lightning, storms, floods or other natural disasters, as well as fires, actions by third parties, other accidents, intentional, mistaken, or incorrect use by the customer, or use under other unusual conditions outside the

responsibility of the Company.

The Company is not liable for any incidental damages (change/disappearance of described content, loss of bus income, disruption of business, etc.) arising from use of the

product or inability to use the product.

The Company is not liable for any damages or lost income arising from failure to observe the described content of the last of the las

 You cannot use information obtained from the measuring sensor or GPS equipped with the product for the purpos which requires high reliability, as the obtained information is just used for a guide. Note that the Company is not liable for any damage or lost income arising from the difference caused

. The Company is not liable for any damages or lost income arising, for example, from malfunction caused by combination with connected devices or software not related to the Captured image data or downloaded data may sometimes be altered or lost due to faults, repair or other handling of the product. The Company is not liable for any damage or lost income resulting from recovery of these data.

It is recommended you keep a copy of important data on your PC's hard disk etc. Whatever the cause of the defect or malfunction may be, the Company assumes no responsibility for alteration or loss of saved data. · Data saved in the product, such as images/videos, might be

altered or lost by an accident, fault, repair or mishandling. Be sure to keep a copy of important contents. Note that the Company assume no responsibility for any damages or lost income resulting from altered or lost contents.

Note that contents data (both charged or free content) saved

to the product cannot be returned to the customer when the product is replaced for repair of a fault, for example.

Although an afterimage may occur when a same screen has been displayed for a long time, it is not a malfunction. You are

recommended to set the sleep time to a short one to avoid occurrence of afterimage and save the battery consumption Although the display used for the product is made using high-precision technology, some pixels (dots) might be lit or out at all times. This is not a malfunction.

It is recommended that you store separate copies of data such as still pictures/videos and music saved on the product on your PC or cloud services, etc. Note, however, that you may your PC or cloud services, etc. Note, nowever, that you may not be able to make copies of any copyrighted data even by the above-mentioned means.

Do not discard the product together with regular trash. Please

cooperate in the collection of the product (including optional accessories) when it is no longer needed to protect the environment and effectively use resources.
"The Company" as appears in the manual refers to your carrier

and the manufacturer (Sony Corporation).

■ Notice Reproduction of the content of "Instruction Manual" in part

or in whole is prohibited.
The content of "Instruction Manual" is subject to change without notice.


Some functions may be unavailable due to change of specification of the OS or change/termination of services. Every effort has been made in the preparation of "Instruction Manual". Should you notice any unclear points, omissions, etc., feel free to contact us.

8

0

15

Names and functions of parts



① Headset jack

④ Earpiece/Speaker*1*2

Switches the touch panel on and off to prevent from erroneous operation during a call/Auto-control for display brightness.

⑥ Display (Touch panel) 7 Speaker*1*2

® Mouthpiece/Microphone*1*2

0


USB Type-C port

1) Power key/Fingerprint sensor

precautions for proper use.

These "Safety Precautions" describe instructions that should be observed to prevent damage to property or

observed and the product is used improperly.



*1 Serious injury: This refers to loss of sight, injury, burns (high- and low temperature), electric shock, broken bones, injuries with residual aftereffects from poisoning etc., and injuries

outpatient.
*2 Minor injury: This refers to injuries, burns (high- and low-temperature), electric shock, etc. that do not require hospital admission for treatment or

If you have a weak heart, set the vibrator or ringtone

If you are wearing any electronic medical equipment, check with the relevant medical electronic equipmen

manufacturer or vendor whether the operation migh

The radio waves from the product might affect electronic medical equipment.

e radio waves from the product might interfere with

equipment that you should be careful of: Hearing aids, implantable cardiac pacemaker, implantable cardioverter defibrillator, other electronic medical equipment,

and other automatically controlled devices or equipment. If you

cardioverter defibrillator, or other electronic medical equipment

check with the medical electronic equipment manufacturer or vendor whether the operation can be affected by radio waves.

part of the product when the display or the camera

Touching damaged or exposed part might cause burns,

The leaking liquid might ignite, catch fire, explode, etc.

Be careful not to allow a pet etc. to bite the product.

If the internal battery leaks or gives off a strange smell, immediately stop using and remove it from the vicinity

Be careful about broken parts or exposed internal

nent operating on high precision control or

Power off the product near electronic devices or

the operation of electronic devices or equipment.

The following are some electronic devices or

use an implantable cardiac pacemaker, implantable

volume carefully.
Sudden vibration or ringtone sounding when for

be affected by radio waves.

injury, electric shock, etc.

incoming call astonishes you and it may affect your

2

12 5G/4G antenna*3

3 Flash/Photo light

5 5G/4G antenna/Wi-Fi@/Bluetooth@/GPS antenna*3

*1 Do not jab with a sharp object such as a needle. Doing so

2 Note that covering these parts with stickers or fingers, etc. may hinder product performance.

3 The antenna is built into the main unit. Covering around the

*4 For details on handling SIM card, refer to "取扱説明書 詳細版

cause damage or a malfunction. Also, battery is built into the

(Full instruction manual)* (Japanese).

*5 The back cover is not removable. Removing forcibly might

antenna by your hand may affect the quality of call/

main unit and not removable by customers

(18) 5G/4G antenna/Wi-Fi® antenna*3

@ microSD memory card/SIM card slot

(14) Main camera

16 mark

(17) SIM card*4

(19) Back cover*5

may cause a malfunction

| O Don't | Indicates an action that is not allowed. | No wet hands | Indicates that handling with wet hands is not allowed. | |
|-------------|---|--------------|--|--|
| No diaments | Indicates that disassembly is not allowed. | Q Do | Indicates compulsory actions in accordance with instructions. | |
| No liquids | Indicates that use in a place where the product is likely to get wet or allowing the product to get | € Unplug | Indicates that the power plug must be disconnected from an outlet. | |

Precautions common to the main unit, internal battery, charging equipment, SIM card, peripheral devices



under a kotatsu or bedding, in direct sunlight, in a car in the hot sun). Doing so might cause fire, burns, injury, electric shock.

Do not put the equipment in cooking appliances

such as microwave ovens, IH cooking heaters, or high pressure containers such as pressure cooke Doing so might cause fire, burns, injury, electric shock

equipment with hands with sand etc. adhered. Doing so might cause fire, burns, injury, electric shock,

waterproof and dustproof properties" (▶P.30).

10

Doing so might cause fire, burns, injury, electric shock,

For waterproofness, refer to "Notes on waterproof and dustproof properties" (▶P.30).

Do not leave the main unit in the reach of children or

persons requiring supervision.

The product uses magnets. If swallowed, there is a risk of choking or serious harm to internal organs.

If the magnet has been swallowed, immediately consult

Do not bring the main unit near medical devices.

The product uses magnets; they may affect pacemakers, variable-pressure hydrocephalus shunts,

and other medical devices. Do not bring the product

near persons using these devices. If you use such a device, consult your doctor before using the product.

Watch the display in an adequately bright place

acuity etc

■ Charging equipment

taking a certain distance from it.
Watching in a dark place or closely might reduce visual

Do not use the specified charging equipment (sold

separately) if the cable is damaged.
Doing so might cause fire, burns, electric shock, etc

If you hear thunder, do not touch the specified

with your hands, fingers, or any part of your body

charging equipment (sold separately).

Warning Be sure to read the following warnings before use.

gnition of flammable gas might cause explosion, fire.

Do not connect the voltage converter (such as a

Doing so might cause ignition, overheating, electric

travel converter for overseas travel) to the specified charging equipment (sold separately).

Doing so might cause fire, burns, injury, electric shock

Although the product has the waterproof property, inserting USB Type-C plug to the product when it is wet might cause electric shock or short-circuit due to the

sture or foreign substance on the product or USB

Type-C plug, or might cause abnormal overheating, fire

amage, fire, burns, or a fault if corrosion occurs.

Doing so might cause fire, burns, electric shock, etc

Use the adapter only on the specified power supply

When charging the battery overseas, use AC adapter

AC adapter (sold separately): 100V AC (Connect to the

Using the incorrect power supply and voltage might

AC outlet for internal household use)
AC adapter (sold separately) that can be used overseas: 100V AC to 240V AC (Connect to the AC

Do not put an excessive force to the connection part with the specified charging equipment (sold separately)

Never connect the USB Type-C plug to the product or the specified charging equipment (sold separately)

Do not touch the cable, charging terminals or power plug of the specified charging equipment (sold

· Remove the power plug from an outlet Turn off the power of the product Failure to do so might cause fire, burns, injury, electric

location before using the product there.
Do not charge the product at a gas station, etc

in particular, do not use the product while filling

Take care not to drop the product at a gas station, etc.;

Ignition of flammable gas might cause explosion, fire,

If you notice anything unusual about the equipment

such as an unusual odor, abnormal noise, smoke generation, overheating, discoloration or deformati during operation, charging or storage, perform the

Turning the power on/off

1 Press and hold Power key until the product

When the product is powered on, the lock screen

Swiping (flicking) the screen up displays the Home

When "ようこそ (Welcome)" appears after the

1 Press Power key and the upper part of the

■ Information

• To restart the product in safe mode (start with almost default

state), press Power key and the upper part of the volume key at the same time \rightarrow Long-touch "Power off" \rightarrow [OK].

1 Press and hold Power key and the upper part

of the volume key at the same time for 10 seconds or more, and release your fingers after the product vibrates three times

product is powered on, follow the onscreen instructions to set the initial settings.

Turning the power on

Turning the power off

volume key at the same time

Forcedly turning the power off

To view the regulatory compliance mark

In the Home screen, slide the screen up →

[Settings] → [About phone] → [Certificates]

Regulatory compliance mark such as FCC ID is

Follow the instructions of a gas station or other such

appears

2 [Power off]

consecutively

displayed on the screen.

FCC ID

Caution Be sure to read the following cautions before use

following measures carefully.

Do not use damaged product or peripheral devices. Doing so might cause fire, burns, injury, etc.

Do not place the product on an unstable or inclined platform. Be careful especially when vibrator is set.

The product might fall and cause injury etc.

Do not use or keep in a place that is very humid,

dusty, or subject to high temperature.

Doing so might cause fire, burns, electric shock, etc.

For waterproofness/dustproofness, refer to "Notes on waterproof and dustproof properties" (▶P.30).

If children use the product, parents or quardians

should give them proper instructions and do not allow them to use the product in the wrong way.

In particular, be careful where small parts are stored, Failure to do so might cause accidental ingestion electric shock, etc.

Be careful about the temperature when using the product continuously or while charging because it might become warm. Also, be careful not to keep touching it unintentionally in a pocket of clothes. when you fall asleep, etc.

The product or the specified charging equipment (sold separately) might become warm when using an app, a call, data communication, watching video, playing a game, etc. continuously or while charging. If you are directly in contact with warmed part con might cause a redness of skin, itch, rash, low temperature burn, etc. depending on your physical condition.

Main unit

Danger Be sure to read the following hazards before use.

Do not throw the product into fire or apply heat. Do not put excessive force such as sticking with a

sharp object (nail etc.), hitting with a hard object (hammer etc.), or stepping on it. Doing so might cause fire, burns, injury, etc.

If the internal substance of the product contacts your eyes or mouth, immediately rinse the eyes or mouth with clean water and then see a doctor right away. The effects of the internal substance of the produc might cause blindness, medical problem, etc.



Do not turn on or flash Flash/Photo light with the





Do not look at a repeatedly-blinking screen for a long time. \bigcirc

Do not allow liquids such as water (drinking water. sweat, seawater, urine of pet animals, etc.), metal parts, or flammable objects to enter to the microSD memory card/SIM card slot of the product. Do not set a microSD memory card or SIM card in wrong insertion, or insert it in wrong orientation. Doing so might cause fire, burns, injury, electric shock,

Do not expose the camera lens to direct sunlight for close time. a long time.

Doing so might cause fire, burns, injury, etc. due to light-

Power off the product or put it in Airplane mode

before boarding an airplane.
Use of mobile phones on board is restricted. Follow the instructions of each airline.

The radio waves from the product might adversely affect n-board electronic equipment. Prohibited acts related to mobile phone usage on an airplane might be punished by law.

The radio waves from the product might affect electronic equipment and electronic medical equipment.

Follow the instructions of each medical facility for

the use of mobile phones on their premises.

Always keep the product away from your ear when you call handsfree, while sounding the ringtone loudly, or during stand-by.

Also, when you play game, play back videos, music, etc. connecting the earphone/microphone, etc. to the product, adjust the volume adequately.

Loud sound is emitted from the product when calling with hands-free set. Even in standby mode, a ringtone or an alarm sound

istening to loud sound for long hours continuously may cause a disability of ears such as deafness. Moreover, too loud sound makes you barely hear the

surrounding sounds and may cause an accident

Doing so might cause fire, burns, injury, etc. because of ignition, burst, heat or leaking of the internal battery. Caution Be sure to read the following cautions before use.

When using the motion sensor, check the safety nd you, hold the product firmly, and do not Failure to do so might cause an accident such as injury.



9

If the display is damaged and when the internal substance etc. leaks out, do not allow it to contact your skin such as face and hands, clothes, etc. loing so might cause injury etc. on your eyes or skir If the internal substance gets into your eyes, mouth, etc.

or contacts your skin or clothes, immediately rinse with n the case of getting into your eyes, mouth, etc., mmediately consult a doctor after rinsing.

Do not discard the product together with other garbage.
Doing so might cause fire, burns, injury, etc. Also, it might cause environmental destruction. When the

product is no longer used, dispose of it according to a ecycling program of your local municipality. If the substance leaks out from the internal battery, do not allow the fluid to contact with your skin of

face hands clothes etc. Doing so might cause injury etc. on your eyes or skin.

If the internal substance gets into your eyes, mouth, etc. or contacts your skin or clothes, immediately rinse with

In the case of getting into your eyes, mouth, etc. nmediately consult a doctor after rinsing. For using the product in a car, check with the bile manufacturer or dealer for the effects by

radio waves before using.

Depending on vehicle model, the radio waves from the product may affect the vehicle's electronic equipment to malfunction. In that case, stop using the product mmediately.

If any skin abnormality develops due to the use of the product, immediately stop using the product, and consult a doctor. Depending on your physical constitution or health, itchiness, a rash, eczema, etc. might develop. hiness, a rash, eczema, etc. might develop. e "Material list" (> P.22) for materials used in each

part of the product. Magnetic components are used in the product's earpiece/speaker (top center of display), speaker (bottom left on back), vibrator (bottom right on back) and main camera (top right of display, top left on

staple, etc.) are attached to the product.

Attached objects might cause injury, etc



charging equipment (sold separately) when connecting the plug to or disconnecting it from an Doing so might cause fire, burns, electric shock, etc.

Do not short-circuit the charging terminal while it is connected to an outlet. Do not touch the charging term Doing so might cause fire, burns, electric shock, etc Do not place heavy objects on a cable of the specified charging equipment (sold separately), or do not apply unreasonable force to the cable such as pulling.
Doing so might cause fire, burns, electric shock, etc

shock, etc.

electric shock, etc.

arately) with wet hands.

cause fire, burns, electric shock, etc.

outlet for internal household use)

separately) into an outlet. secure inserting might cause fire, burns, electric

Clean dust from the power plug. Using it with dust adhered might cause fire, burns, Firmly insert the specified charging equipment (sold

Caution Be sure to read the following cautions before use.



Do not touch the specified charging equipment (sold separately) continuously when it is co





20





These items are not included in the package.

Purchase a specified charger (sold separately) The battery is built into the product.

Illustrations used in this manual are just images for explanations. They may be different from actual ones.

• microSD memory card • Earphones

Before you start using the product, make sure that

クイックスタートガイド

(Quick Start Guide)


USB Type-C™ cable

you have all these packaged items with the

Packaged items

Main unit

· AC adapter



② Second microphone*1*2 3 Front camera

⑤ Proximity/Light sensor*2:


10 Volume key/Zoom key

Safety Precautions (Observe Strictly) ■ Before using this product, thoroughly read these safety

injury to the customer or others using the product.

The following symbols indicate the different levels of injury or damage that may result if the guidelines are not

his symbol indicates that "death or




requiring hospital admission for treatment or long-term hospital attendance as an

long-term hospital attendance as an outpatient.

*3 Property damage: This refers to extended damage to buildings, furniture, livestock, pets, etc.

■ Explanation of graphic symbols

| Sont | Indicates an action that is not allowed. | No wet hands | Indicates that handling with wet hands is not allowed. |
|---------------|--|--------------|--|
| <u>D</u> | Indicates that disassembly is not allowed. | Q | Indicates compulsory actions in accordance with instructions. |
| S) liquids | Indicates that use in a place where the product is likely to get wet or allowing the product to get wet is not allowed. | Unplug | Indicates that the power plug must be disconnected from an outlet. |



Do not splash sand, soil or mud, or do not directly place the equipment on it. Also, do not touch the



3

animals, etc.)

Do not charge the equipment when it is wet will liquids such as water (drinking water, sweat, seawater, urine of pet animals, etc.). Also, do not charge the equipment in a place where water comes in contact such as bathroom or near a Doing so might cause fire, burns, injury, electric shock,

For waterproofness, refer to "Notes on waterproof and dustproof properties" (▶P.30).

Do not charge the equipment when it is wet with

SIM card

the product.

Your phone number etc. is

Attaching SIM card

cover straight out.

Before attaching SIM card, make sure to turn off

Put your fingertip (nail) into the groove of the

microSD memory card/SIM card slot and draw the

1 Remove the tray from the main unit

recorded in SIM card.

Do not subject the product to strong pressure or break the product. Especially when bringing the product putting in a pocket of clothes, do not let the product hit against surroundings or being put between the objects.
Doing so may cause fire, burns, injury, etc. due to damage of the internal battery.

*The following are examples that you should be careful Sitting or squatting with the product put in a pocket of

trousers or skirt

Putting the product in a pocket of outer wear and catching them in a door or a door of car

 Stepping on the product on a soft object such as a sofa, bed or bedding, or on a floor
 Putting the product into a seat of train or bus Do not disassemble or modify the equipment.

oing so might cause fire, burns, injury, electric shock, Do not try to remove the internal battery from the

Doing so might cause fire, burns, injury, etc The back cover cannot be removed. Do not try to remove it from the product. Also, if the product is swollen due to the swollen battery, etc., do not try to ove the back cover or press it forcibly.

Do not let the equipment get wet with liquids such as Doing so might cause fire, burns, injury, etc

 \bigcirc

where flammable gas may be present, or a place where dusts are generated. Stop charging the product if you are charging it.

shock, etc.

connected to the product.

when it is wet.

and voltage.

overcharge etc

If charging does not finish after specified time, stop **charging.**Failure to do so might cause fire, burns, injury, etc. due Always turn off the product before you enter a place

 \bigcirc

12

(8)

2 Set SIM card into the tray with the IC (metal)

Surely set SIM card into the tray not to come off.

Pay attention to the location of the notch.

Notch—

3 Keep the product horizontal and then push

Pay attention to the direction the tray is being

memory card/SIM card slot cover.

Do not allow liquids such as water (drinking water,

the headset jack.

dustproof properties" (▶P.30).

sweat, seawater, urine of pet animals, etc.) to get inside the charging terminal, the USB Type-C port, or

Doing so might cause fire, burns, injury, electric shock

For waterproofness, refer to "Notes on waterproof and

the product.
Using devices other than specified, or those with

Do not subject the equipment to strong force.

cause fire, burns, injury, electric shock, etc.

Use only optional parts specified by the Company for

inite manufacturer, retailer, or specifications might

Warning Be sure to read the following warnings before use.

impacts, or vibration such as letting it fall, stepping on it or throwing it.

Doing so might cause fire, burns, injury, electric shock,

Do not allow conductive materials (such as metal

objects and pencil lead) to come into contact with the charging terminal, the USB Type-C port, or the

Do not cover or wrap the equipment with a cloth or

headset jack, or allow dust to get inside of it. Doing so might cause fire, burns, injury, electric shock,

bedding in use or while charging.

Doing so might cause fire, burns, et

Firmly press where circled O, and check that there

is no gap between the main unit and the microSD

part facing up

the tray in straight

pushed in.

SIM card

Back

rC (metal) par

Front

Use of the product in the wrong way might cause accidental ingestion, injury, electric shock, etc

Keep the equipment out of the reach of babies or infants, and store it where pets cannot touch it. such as the microSD memory card/SIM card tray.

When you disconnect a power plug of the specified charging equipment (sold separately) from an outlet, do not apply excessive force to it such as pulling the cable. Instead, hold the adapter main unit to Pulling the cable of the specified charging equipment (sold separately) might damage the cable causing fire, burns, electric shock, etc.

When plugging/unplugging the specified charging equipment (sold separately) into/from the product, plug/unplug it straight toward the product without applying excessive force such as pulling the cable. Incorrect plugging/unplugging might cause fire, burns, injury, electric shock, etc.


If the charging terminal is deformed such as being bent, stop using immediately. Do not use it with the deformation restored. Doing so might cause fire, burns. iniurv. etc. due to short-circuit of the charging terminal.

Always remove the power plug from an outlet when Keeping it plugged in might cause fire, burns, electric

Immediately remove the power plug from an outlet if liquids such as water (drinking water, sweat, seawater, urine of pet animals, etc.) get adhered.

etc. due to short-circuit by adhered object etc. Before cleaning, remove the power plug from an

Failure to do so might cause fire, burns, electric shock,



Doing so might cause a burn etc.





Warning Be sure to read the following warnings before use.

If you wear electronic medical equipment such as an implantable cardiac pacemaker or an implantable cardioverter defibrillator, carry or use the product 15 cm or more away from the implant at all times. effects on the operation of the electronic medica

equipment.

If you need to use electronic medical equipment other pacemakers or implantable than implantable cardiac pacemakers or implantable cardioverter defibrillators outside medical facilities such as treating at home, consult the relevant medical electronic equipment manufacturer for effects on the equipment by radio waves.

es from the product might have harmful equipment. If there is any chance that the distance between the

product and a person closest to you might get shorter than 15 cm such as when you cannot freely move around, set the product not to emit radio wave in advance (Airplane mode, power off, etc.). A person in close proximity to you might wear electronic medical equipment such as an implantable cardiac pacemaker or an implantable cardioverter defibrillator. T radio waves from the product might have harmful effects on the operation of the electronic medical equipment.

Follow the instructions given by the respective medical facility regarding use of the product on their

The radio waves from the product might have harmful

21

28

35

42

- The touch panel is designed to be lightly touched by fingers Do not apply strong pressure with your fingers or sharp pointed objects (such as fingernails, ballpoint pens and pins) to the touch panel. In the following cases, the touch might not respond. Also, it may cause malfunction.
- Operation with gloves · Operation with fingernails

■ Display (Touch Panel)

- Operation with foreign object on the touch panel
 Operation with protective sheet or seal on the touch panel
 Operates when the display is wet with water droplet or
- Operation with wet or sweaty fingers Operation under water
- Putting stickers or sheets (e.g. commercially available protective films, peep prevention sheets) on the display might hinder correct operation of the touch panel.
- When carrying the product in your pocket or bag, take care not to put the touch panel close to metals or other conductive

erials, as it might cause false operation of the touch panel

■ Internal battery (The internal battery of the product is a

lithium-ion battery) The internal battery is not fully charged at the Li-ion 00 time of purchase. Charge the internal battery before using the product. Charge the internal battery if you have not used the product for a long time.

SIM card

- Do not forcibly remove or insert SIM card. Be careful not to exert excessive force when inserting the card into your You are responsible for any damage caused by inserting your
- SIM card into other IC card reader/writer etc. Do not put stickers etc. on the SIM card.
- Do not insert SIM card with conversion adapter attached. Doing so might cause a malfunction. Do not damage the SIM card by using the product in a hot
- place, dropping into fire, contacting to the metal parts with foreign object, giving an impact, bending, applying load, wetting, etc. Doing so might cause loss of data or a

Material list

Main unit

part, side part) with glass Zoom key, Back cover) xterior case (cover of roSD memory card/SIM card slot) glass fiber) Transparent plate (Display) Transparent plate (Camera Hardened Flash/Photo light Acrylic resin Power key/Fingerprint sensor Epoxy resin Coating Earpiece/Speaker (upper part) sh, Speaker (lower part) Rubber seals on the cover of Silicon rubbe icroSD memory card/SIM card slot Tray of microSD memory card/ Polycarbonat SIM card glass fiber) + SUS plate

When photographing important occasions etc., take a trial shot

and check the shot image to make sure it is correctly shot.

You are not allowed to copy, distribute, publish, modify or edit

the data you shot, recorded or downloaded using the product

without consent of the copyright holder, except for personal use such as copying or quoting where provided for under the

In addition, do not use or modify portraits or names of othe

individuals without the consent, as it might infringe on rights

Note that shooting and recording might be restricted at some live performances, shows and exhibitions even for personal

Be careful about the copyright and portrait right when posting

For more notes on the display, etc., refer to "取扱説明書 詳細

Do not shoot in a place where shooting is prohibited

■ Copyrights and rights of portrait

Handling precautions

These precautions are provided to prevent the product from damage and ensure that performance can be fully demonstrated. Thoroughly read these precautions to ensure correct use. For more details, refer to "取扱説明書 詳細版 (Full instruction manual)" (Japanese).

■ Precautions common to the main unit, internal battery, charging equipment, SIM card, peripheral devices

- Do not apply excessive force to the product during use. Be sure not to put the product into a tightly packed bag or place a heavy object on the product in a bag. Sitting on the product in your pocket might damage the display or internal circuit Keeping an external device connected to the USB Type-C port or headset jack might cause damage of the connected board or cause a malfunction.
- port or headset jack might cause damage of the connector or a malfunction. Such damage and malfunction are not covered by the warranty, even if there is no external damage.
- To ensure waterproof property (equivalent to IPX5 and IPX8) of the product, use with the cover of microSD memory card/ SIM card slot tightly closed. Note that the waterproof property s not guaranteed in every usage condition
- Do not allow water to get inside of the product or splash water on the specified charging equipment (sold separately) or optional accessories. Do not open or close the cover of microSD memory card/SIM card slot in the rain or with water droplets on the surface of the product. Doing so might cause vater intrusion resulting in internal corrosion Malfunctions determined to be caused by water intrusion are not covered by the warranty.
- Waterproof/dustproof performance might not be maintained if the product has an outward abnormality such as damage or deformation. In that case, make an inquiry to Repair and Delivery Support Center.
- For the following products, do not use them in extremely hot, cold (Use within an ambient temperature range of 5°C to 36°C and humidity range of 35% to 85%. However, temporary use at an ambient temperature range of 36°C to 40°C and humidity range of 86% to 90 % is allowed.)
- SIM card (attached to the main unit)

22

23

properties The product has a waterproof property equivalent to JIS waterproof grade (JIS C 0920) IPX5*1 and IPX8*2, as well as a dustproof property equivalent to JIS dustproof grade IP6X*3 on the condition that the cover of microSD memory card/SIM card slot is securely attached (based on in-house testing) Before using the product, thoroughly read "Important items to remember before use" to ensure correct use. Failure to follow the contents described in the sections might cause intrusion of

Notes on waterproof and dustproof

water, sand or other foreign material, resulting in overheating, Ignilion, electric shock, injury or a malfunction.

1 IPX5 equivalent means that the product will maintain its operability as a phone even if it is sprayed with water from a 6.3 mm diameter nozzle at a distance of about 3 meters for

- more than 3 minutes at a rate of about 12.5 liters per minute from any direction. *2 IPX8 equivalent means that the product will maintain its operability as a phone with no water getting inside the main unit even if it is gently submerged in a tank of still tap water
- at room temperature to a depth of 1.5 meter for about 30 *3 IP6X equivalent means that the product will securely
- maintain its function of no grit and dust getting inside the main unit even after it has been placed in an apparatus wil grit and dust of diameters of 75 μ m or less and shaken for 8 Since operation of the product on each usage scene was

confirmed based on the above assumption, proper operation of the product in every possible condition during actual use is not guaranteed. Malfunctions determined to be caused by mishandling by the customer are not covered by the warranty.

30

37

44

· Peripheral devices Do not use in places subject to lots of dust or vibration. Doing

For the following products, do not use them in extremely hot, cold

(Use within an ambient temperature range of 5°C to 35°C and humidity range of 35% to 85%.)

- · Charging equipment punishable by some regulations. Using or charging the product in a bag or when it is covered. vith bedding might cause a malfunction
- Clean the USB Type-C port and headset jack with dry cotto swabs etc. every now and then. Soiled terminals might cause poor connection. Do not exert strong force to clean the USB Type-C port and headset jack to prevent deformation
- Clean the product with a soft dry cloth (e.g. wiping cloth for
- eyeglasses). Forceful rubbing with a dry cloth might scratch the display. The display might be stained if splash or smear is left attached to the surface. Wiping the product using alcohol thinner, benzene, detergent, glass cleaner, etc. might erase
- the printing on the exterior case or cause a malfun Use as far away as possible from land-line phones, TVs and
- adios. Use of the product nearby might affect them. The product might become warm while talking, charging or during other operations, depending on the situation, but this
- Do not place near corrosive chemicals or in places where corrosive gas is generated. Doing so might cause a
- Do not use outside when you can hear thunder. Doing so night risk lightning strikes and electric shock.
- Be sure to use only the specified peripheral devices. Use of ner peripheral devices might cause a malfunction Do not put the product in a cooking apparatus such as microwave oven or a pressure vessel. Doing so might cause
- a malfunction. The customer is not allowed to disassemble, modify or repair
- the product. Doing so might cause a malfunction.

 Modification of the product is in violation of the Radio Law
 and Telecommunications Business Act. Do not allow a part of your body such as finger or conductive foreign objects (metal fragments, pencil leads, etc.) to come into contact with or to enter the USB Type-C port or headset
- jack. Doing so might cause a malfunction. In the event that the product gets wet while charging, immediately disconnect the plug of the specified charging
- equipment (sold separately).

Precautions on charging Important items to remember before use

31

24

- Make sure that the cover of microSD memory card/SIM card effective when the cover is securely closed. Do not open or close the cover of microSD memory card/SIM
- card slot if the product or your hands are wet.

 Do not sink the product in liquids other than tap water (seawater, pool water, water of hot spring, water with soap detergent or bath salt contained, alcohol, juice, seasonings etc.) or do not splash such liquid to the product. Also, do no use in a place where urine of pet animal is splashed. If it is splashed on the product, immediately wash the product with
- Do not put the product directly on sand at a beach etc. Sand or other small particles might get inside the earpiece/speaker, mouthpiece/microphone, speaker, or second microphone causing the volume to drop. If sand gets inside of the main unit, it might cause overheating or a malfunction.
- Do not use the product underwater. Do not leave the product in a humid place such as a hathroom or kitchen for an extended period of time.

 Even after draining, water might remain on the product.

 Although you can use the product, do not place it near things
- that must not get wet. Also, take care not to wet your clothes water if it becomes temporarily hard to hear the sound
- due to water remaining in the earpiece/speaker, mouthpiece, microphone, speaker, or second microphone. Do not spray the product with high-pressure water o submerge it in water for extended periods of time, as the product is not designed to withstand high water pressure.

 Do not wash the product in a washing machine or ultrasound
- · Do not immerse the product into a bathtub. The product is not esistant to high temperatures.
- resistant to high temperatures.

 Extreme changes in temperature generates condensation causing a malfunction. Wait until the main unit reaches room temperature before you bring the product from a cold place into a warm bathroom . The product does not float on water.

For more details, refer to "取扱説明書 詳細版 (Full instruction

The optional accessories are not waterproof. Check the ollowing before and after charging.

a dry cloth, etc.

Never charge the battery if the product is wet. Doing so might

cause fire, burns, injury, electric shock, etc.

Check that the product is not wet. If you are charging the battery just after the product gets wet, drain water well and wipe the remaining water off with a clean dry cloth.

Do not use the product while driving an automobile or motorized bicycle, riding a bicycle or walking. Use of a mobile phone while driving a car or motorbike is prohibited by law. Use of a mobile phone while riding a bicycle might be

orientation of the connector is correct. Unless it is correct, it

When using the specified charging equipment (sold separately) or an external device, insert/remove the connector straight to/from the terminal. Make sure the

Do not expose the camera lens to direct sunlight for an

extended period. Doing so might cause a malfunction.

Do not use, store, and leave the product in places subject to

places that get extremely cold, and in humid or dusty places

direct sunlight (e.g. in automobiles), places that get hot,

Do not place the product on an unstable or inclined platform
 Be careful especially while charging or when vibrator is set.

The product might fall and cause a malfunction etc.

Do not exceed the rating of outlet or wiring device when

charging the product, for example, by starburst connection

Since the battery is built into the product, you cannot replace

Do not forcefully press, tap or intentionally subject the display to strong impact. Doing so might cause scratching or

Do not forcefully press the keys or display surface with your

fingernails or hard objects. Doing so might cause scratch

it yourself. For replacing the battery, make an inquiry to an au Style/au shop or Customer Center.

night cause a malfunction.

Main unit

Doing so might cause a malfunction.

- · Do not touch the specified charging equipment (sold separately)
- with wet hands. Doing so might cause electric shock.

 Do not splash water over the specified charging equipment (sold separately) when using them. Do not use them near water such as in a bathroom, shower room, kitchen or washroom. Doing so might cause fire, burns, electric shock, or malfunction. Do not bring them into a bathroom etc. even if you do not charge the product with them. Doing so might cause fire, burns, electric shock, or malfunction. ■ Draining water when the product gets wet

Drain the following parts: Earpiece/speaker, Mouthpiece/microphone, Speaker, USB Type-C port, Second microphone, Headset jack, Power key/ Fingerprint sensor, Volume key/Zoom key, the cover of microSD memory card/SIM card slot. Camera lens (peripheral part of If water remains, clothes or bag might get w be barely heard. Drain in the following steps ains, clothes or bag might get wet or sound might

- 1 Wipe off water remained on the product with
- 2 Hold the product firmly and shake it approximately 20 times, then turn upside
- down and shake it 20 times again When shaking the product, check the safety around you and hold it firmly enough not to drop it.
- 3 If water flows out from the inside of the product, wipe it off with a dry cloth etc. Face the product downward and push it on a cloth to
- wipe off the water. Turn the upside down and wipe off the water 4 Place a dry towel or cloth under the product
- and leave it for a couple of hours at roomtemperature to dry the product is not dried enough, you can barely
 - hear the sound. Leave the product enough time to dry before use. 32

Please refer to the WHO website if you would like more detailed

https://www.who.int/news-room/fact-sheets/detail/

- electromagnetic-fields-and-public-health-mobile-phones Please refer to the websites listed below if you would like to know more detailed information regarding SAR. Ministry of Internal Affairs and Comm https://www.tele.soumu.go.jp/e/sys/ele/index.htm
- Association of Radio Industries and Businesses websit https://www.arib-emf.org/01denpa/denpa02-02.html https://www.au.com/mobile/product/sar-list/ (Japanese)
- Support page of Xperia official webs https://www.sony.jp/xperia/product/SAR/ (Japanese)

Intellectual property rights

Micro

trademarks of SD-3C, LLC.

Bluetooth

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation and their subsidiaries is

Alliance®.
• The microSD logo, microSDHC logo and microSDXC logo are

USB Type-C™ is a trademark of USB Implementers Forum.

N is a trademark or registered trademark of NFC Forum, Inc. in the USA and other countries.
 The product is licensed under the MPEG-4 visual and AVC

patent portfolio license for the personal and non-commercial

the MPEG-4 visual standard ("MPEG-4 video") or the AVC standard ("AVC video") and/or (ii) decoding MPEG-4 or AVC

use of a consumer for (i) encoding video in compliance with

video that was encoded by a consumer engaged in a persona

and non-commercial activity and/or was obtained from a video

provider licensed by MPEG LA to provide MPEG-4 and/or AVC video. No license is granted or shall be implied for any other use. Additional information including that relating to

promotional, internal and commercial uses and licensing may be obtained MPEG LA, LLC, (See https://www.mpegla.com) MPEG Layer-3 audio decoding technology licensed from Fraunhofer IIS and Thomson.

The software installed on the product or part of it may not be altered, translated/adapted, reverse-engineered, decompiled

or reverse-assembled and any such actions are prohibited. "Y=" and "SON", or product names, service names, and logo marks used in this manual are registered trademarks or trademarks of Sony Group Corporation or its affiliated companies. All other product names, service names, company

names, and logo marks are trademarks, registered trademarks, or titles of respective companies.

• FeliCa is a contactless IC card technology developed by Sony

Corporation.
• In context, TM and ® mark may be omitted.

Wi-Fi® is a trademark or registered trademark of Wi-Fi

■ Radio Frequency (RF) exposure and Specific Absorption Rate (SAR)

39

46

evaluation of scientific studies.

These guidelines establish permitted levels of radio wave

exposure. The guidelines include a safety margin designed to sure the safety of all persons and to account for any variations Specific Absorption Rate (SAR) is used to measure radio

frequency energy absorbed by the body when using a mobile phone. The SAR value is determined at the highest certified power level in laboratory conditions, but because the phone is designed to use the minimum power necessary to access the chosen network, the actual SAR level can be well below this value. There is no proof of difference in safety based on

required, tests are performed when the phone is placed at the ear and when worn on the body. For body-worn operation, the phone has been tested when positioned a minimum of 10 mm from the body without any metal parts in the vicinity of the phone or when properly used with an appropriate Sony Corporatio accessory and worn on the body. Use of the phone other than as tested may impact SAR and result in non-compliance such RF exposure limits. For devices which include "WiFi hotspot" functionality, body-worn SAR measurements for operation of the device operating in WiFi hotspot mode were taken using a separation distance of 10 mm. Use of third-party ies may result in different SAR levels than those For more information about SAR and radio frequency exposure go to: https://www.sonv.ip/xperia/product/SAR/ (Japanese)

· Any rights not expressly granted herein are reserved. All other

trademarks are property of their respective owners

- product, data communication may be performed automatically by some apps, resulting in high data communication charges. Therefore, subscription to a data communication charge discount service or flat late plan is recommended.

forget to disconnect, the call charges may be higher.

Mobile Phone Etiquette

following places!

- or motorbike, or riding a bicycle. Use of mobile phones while driving a car or motorbike is prohibited by law (Use of mobile phones while riding a bicycle may also be punishable by law). In addition, stay alert to the traffic around you even when
- instructions of each airline.

After-sales service ■ When asking for repair

or repair, make an inquiry to Repair and Delivery Support

| During the warranty period | Repairs will be done based on the terms of services of the free-of-charge repair warranty |
|-----------------------------------|---|
| Outside the warranty period | We shall repair the product for a charge as requested by the customer if repair renders usable. |

- · Before handing in the product for repair, make a backup of the ory since they may disappear during rep Note that the Company shall not be liable for any damages and loss of income should the contents of memory be altered
- · Recycled parts that meet the Company's quality standards are Your old terminal collected by replacement mobile phone delivery service is serviced for reuse and recycled as a
- service are collected and recycled by the Company. They cannot be returned to customers. The product which is processed, remodeled, analyzed (including by modifying or analyzing the software (including by rooting etc.), reverse engineering, decompiling, reverseobling), or repaired by an unauthorized repair office is not

replacement terminal. Also, parts replaced through after-sales

assembling), or repaired by an infautionized repair onlice covered by the warranty and repair may be refused. The battery built-into the main unit is not covered by free-of-charge repair warranty, as it is a consumable part. Performance parts for repair

The Company retains performance parts for repair of the main unit and its peripherals for four years after discontinuation of production. "Performance parts for repair" refers to parts required for maintaining the functions of the product.

model is on file at the FCC and can be found under the

Display Grant section of https://www.fcc.gov/oet/ea/fccid after searching on FCC ID PY7-37016L. Additional SAR-related

information can also be found on the Mobile and Wireless Forum at https://www.mwfai.org/.

In the United States, the SAR limit for mobile phones used by the public is 1.6 watts/kilogram (Wkg) averaged over one gram of tissue. The standard incorporates a margin of safety to give additional protection for the public and to account for

* This paragraph is only applicable to authorities and customers in the United States.

any variations in measurements.

■ Provisions for free-of-charge repair Please notify us of the production number (IMEI number) for repair request. The production number (IMEI number) can be

- checked on the product main unit, sticker on the outer packaging box etc. During the warranty period, we will repair the product free of charge for the malfunction under the condition that it is used correctly in line with the directions given in the instruction
- 3. Even if the warranty period has not expired, a fee will be charged for repair under the following circumstances. (or, repair may not be possible).

 ① The product has not been used correctly in line with the
- directions given in the instruction manual. The malfunction or damage is due to unauthorized repair or modification of the product.
 The product has been repaired other than at our specified

The malfunction or damage is due to negligence in use or

- handling, or due to an accident. There are signs of the product having been dropped, wet, exposed to humidity The malfunction or damage is due to natural disa (earthquakes, storm or flood damage, etc.), fire, salt
- 4. Repair may not be possible depending on the degree of 5. The Company shall have no liability for any damage or lost

damage, abnormal voltage, etc.

- income resulting from the malfunction of the product. 6. The Company shall not bear any responsibility for accidents resulting from use of the product having been connected to unspecified devices.

 7. Do not accept requests for service calls to the owner's home,
- place of business, etc. 8. This warranty is valid only in Japan. This warranty surrantees repair free of charge during the period and under the conditions specified on this warranty card. Thus this warranty does not limit the legal rights of the

owner with respect to the issuer of this warranty card (the

This mobile phone model SOG14 has been designed to comply with applicable safety requirements for exposure to radio waves. These requirements are based on scientific guidelines that

include safety margins designed to assure the safety of all

The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR.

Tests for SAR are conducted using standardized methods with

the phone transmitting at its highest certified power level in all

SAR data information for residents in countries/regions that have

For body worn operation, this phone has been tested and meets

The highest SAR value for this model phone tested by Sony for

In the case where the phone is worn on the body, the highest tested SAR value is 1.07 W/kg (10g).

While there may be differences between the SAR levels of

various phone models, they are all designed to meet the

adopted the SAR limit recommended by the International

Commission on Non-Ionizing Radiation Protection (ICNIRP),

example European Union, Japan, Brazil and New Zealand

RF exposure guidelines when used with an accessory that contains no metal and that positions the handset a minimum of 5 mm from the body. Use of other accessories may not ensure compliance with RF exposure guidelines.

which is 2 W/kg averaged over ten (10) gram of tissue (fo

relevant guidelines for exposure to radio waves.

use at the ear is 0.39 W/kg (10g)

persons, regardless of age and health

quarantor) or any other business person or enterprise

An after-sales service membership program on a monthly basis called "Repair and Delivery Support Wide with Cloud" is

29

36

43

available for using your au/UQ mobile terminal for a long time without worries. This service expands coverage for many publes including malfunction, theft and loss.

or monthly charge and details of the service, refer to au/UQ mobile homepage. For au users

■ Repair and Delivery Support Wide with Cloud

- cloud/ (Japanese) For UQ mobile use https://www.uqwimax.jp/mo cloud/ (Japanese)
- * The contents of services are subject to change without notice.

https://www.au.com/mobile/service/kosho-funshitsu-wide-

The SIM card is lent to you by your carrier. In case of loss or damage, the card will be replaced at your expense. When a malfunction is suspected, or in case of theft or loss, make an inquiry to Repair and Delivery Support Center, an au Style/au

FCC Statement for the USA

subject to the following two conditions

This device complies with Part 15 of the FCC rules. Operation is

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

Any change or modification not expressly approved by Sony may void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable

installation. This equipment generates, uses and can radiate

radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no

If this equipment does cause harmful interference to radio or

television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct

The interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for

the interference by one or more of the following measures:

protection against harmful interference in a residential

guarantee that interference will not occur in a particular

shop or Toyota store.

mobile phones This model SOG14 mobile phone complies with Japanese

technical regulations and international guidelines regarding exposure to radio waves.

This mobile phone was designed in observance of Japanese echnical regulations regarding exposure to radio waves*1 and limits to exposure to radio waves recommended by a set of equivalent international guidelines.
This set of international guidelines was set out by the

Specific Absorption Rate (SAR) of

nternational Commission on Non-Ionizing Radiation Protection (ICNIRP), which is in collaboration with the World Health Organization (WHO), and the permissible limits include a substantial safety margin designed to assure the safety of all persons, regardless of age and health condition. The Japanese technical regulations and international guidelines define the limits using a unit of measurement known as the Specific Absorption Rate (SAR), which represents the average amount of radio frequency energy absorbed by the human. The SAR limit for mobile phones is 2.0 W/kg. The highest SAR value or this mobile phone when tested for use near the head is 1.83

be slight differences between the SAR levels for each product, but they all satisfy the limit.

This is due to automatic changes to the power level of the device to ensure it only uses the minimum required to reach the network. Therefore in general, the closer you are to a base station, the lower the power output of the device. his mobile phone can be used in positions other than against

W/kg*2 and when worn on the body is 0.769 W/kg*2. There may

Please keep the mobile phone farther than 1.5 cm away from your body by using such as a carrying case or a wearable accessory without including any metals. By doing this, this mobile phone complies with Japanese technical regulations and international guidelines regarding exposure to radio waves. The World Health Organization has stated that "a large number of this behave been performed over the last that decades to of studies have been performed over the last two decades to of studies have been performed over the last two decades to assess whether mobile phones pose a potential health risk. To date, no adverse health effects have been established as being caused by mobile phone use.*

1 Technical regulations are defined by the Ministerial Ordinance Related to Radio Law (Article 14-2 of Radio

Equipment Regulations).
*2 Including other radio systems that can be simultaneously

Foreign Exchange and Foreign Trade Act

The products may be subject to the application of the Foreign

In addition, the Export Administration Regulations (EAR) of the United States may be applicable.

requested to follow the necessary procedures at their own

ponsibility and cost

details about procedures.

In cases of exporting or reexporting the products, customers are

Please contact the Ministry of Economy, Trade and Industry of Japan or the Department of Commerce of the United States for

Exchange and Foreign Trade Act and other related laws and

38

45

33

Do not use a remodeled product. Use of a modified device.

conformance of specified wireless equipment based on the

of it, the "Technical Compliance Mark 🕏" can be checked

up → [Settings] → [About phone] → [Certificates]

Radio Law and Telecommunications Business Act.

Take care not to place magnetized items such as magnetic

Do not bring magnetized cards such as cash cards, credit

When you put the product in your pocket or bag, take care

Take care with using a strap whose member is a hard

or when used in a humid location or in a place where

may cause scratch or damage.

that the display does not come in contact with metal objects

or other hard objects, as it might cause a scratch or damage

When suddenly brought into a warm place from a cold place,

temperature suddenly changes (e.g. near the air discharge

port of an air conditioner), water droplets (i.e. condensa may be formed inside of the product. Note that when used under such conditions, the humidity might cause corrosion or

While writing or reading data to or from a microSD memory

card, do not subject the product to vibration or impact, o

turn off the power. Doing so might cause loss of data or a

Do not cover the proximity/light sensor with your finger or put

Notes on using Bluetooth®/wireless

The connections between the product and all other Bluetooth® and wireless LAN (Wi-Fi®) devices have not been confirmed. Therefore, connections with all Bluetooth® and wireless LAN (In the product of the product

This product supports security reatures for wheless communications that are compliant with the Bluetooth® and wireless LAN (Wi-Fi®) standard specifications, but the security may not be sufficient depending on the usage environment

ommunication using Bluetooth® or wireless LAN (Wi-Fi®)

Wireless LAN (Wi-Fi®) has the advantage that it can be freely

The Company assumes no responsibility for leakage of data or

(Wi-Fi®) communication.
Since Bluetooth® and wireless LAN (Wi-Fi®) functions use the

same frequency band, using the both functions at the same

may cause radio wave interference resulting in decreased communication speed or disconnection from the network. If connection fails, stop using either of the Bluetooth® and wireless LAN (Wi-Fi®) functions.

tion that may occur during Bluetooth®/

connected anywhere within the radio wave range, as it uses

radio waves for exchanging information. At the same time, there is a risk that a malicious third party may obtain unauthorized access if security settings have not been configured. You are recommended to configure security settings before using wireless LAN (Wi-Fi®) at your decision

LAN (Wi-Fi®) functions

(Wi-Fi®) devices are not guaranteed.

and responsibility.

This product supports security features for wireless

and configuration. Be careful when making data

a sticker on it. Doing so might hinder the proximity/light sensor from detecting the ambient brightness and functioning

erial such as metal because it can touch the display and

cards, speakers and TV sets near the product, as it might cause a malfunction.

Putting a strong magnetism close to the product might cause

cards and prepaid cards closer to the product. It might cause

Radio Law/Telecommunications Business Act, and as a proof

Checking procedure: In the Home screen, slide the screen

If modifications of the internal components of the product are

made, the certification of conformity with the technical standard conformance etc. becomes invalid. Do not use the

product with the certification invalid, as it is a violation of the

es the Radio I aw and Tele

a false operation

a malfunction.

When your phone or Bluetooth® handsfree is turned on, it emits low levels of radio frequency energy. International safety guidelines have been developed through periodic and thorough

Products with radio transmitters sold in the US must be certified by the Federal Communications Commission (FCC). When

■ United States

TO RADIO WAVES. This mobile phone model SOG14 has been designed to comple

phone model when tested for use by the ear is 0.81 W/kg*, when worn on the body is 0.66 W/kg* and when WiFi hotspot mode is 0.66 W/kg. For body-worn operation, the phone has been tested when positioned a minimum of 10 mm from the body without any metal parts in the vicinity of the phone or when properly used with an appropriate accessory and worn on the body. For devices which include "WiFi hotspot" functionality, SAR measurements for the device operating in WiFi hotspot mode were taken using a separation distance of 10 mm. Use of

US, it must be tested and certified by the Federal Communications Commission (FCC) that it does not exceed the limit established by the government-adopted requirement for safe exposure*. The tests are performed in positions and locations (i.e., by the ear and worn on the body) as required by the ECC for each model. The ECC has granted an Equipment Authorization for this phone model with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. While there may be differences between the SAR levels of various phones, all mobile phones granted an FCC equipment authorization meet the government requirement for safe exposure. SAR information on this phone

<For UQ mobile Users ■My au app



40

http://kddi-l.jp/JyO Message



0120-925-919



To browse homepages, download apps, communicate using apps, send/receive e-mails and configure various settings on the product, connection to the Internet is required and data communication charge applies.

· Do not listen to music or watch videos, etc. while driving a cal

walking. Surrounding sounds may not be heard clearly, and gazing at the screen might distract your attention causing a traffic accident. Be especially careful at railroad crossings, station platform and pedestrian crossings. Use of mobile phones on board is restricted. Follow the

THIS PHONE MODEL HAS BEEN CERTIFIED IN COMPLIANCE WITH THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE

with applicable safety requirements for exposure to radio waves.

Your wireless phone is a radio transmitter and receiver. It is standards include a safety margin designed to assure the safety

My UQ mobile (app) My For download URL

http://kddi-l.jp/mFH (Japanese ■au Support (web) URL

Al answers you soon all day and our

URL http://kddi-l.jp/QJo

URL



of the product rises during use. When the mark is displayed, there is a risk of burns if you continue using the product while holding it in your hands. In this case, please refrain from holding it in your hands.

■ Do not put a sticker, etc. on the proximity/light sensor. Doing

Usually use the product with the cover of microSD memory

Do not allow liquids, metal and other foreign objects to get inside the USB Type-C port, headset jack, microSD memory

card/SIM card slot, earpiece/speaker, mouthpiece/ microphone, speaker, second microphone, etc. Doing so

Do not give strong impact on the product such as dropping, throwing, stomping. Doing so might cause a malfunction.

Do not put the product directly on sand at a beach etc. Sand or other small particles might get inside the earpiece/speaker,

mouthpiece/microphone, speaker, or second microphone

To prevent possible hearing damage, do not listen at high volume levels for long periods.

This mark is displayed when the surface temperature

causing the volume to drop. If sand gets inside the product, it

vater might get inside and cause a malfunction

might cause a malfunction.

might cause a malfunction.

lisplay always turned off while receiving a call or during a

card/SIM card slot firmly closed. If the cover is open, dirt or

Notes on data communication charge · Since a constant Internet connection is possible with the

Notes on Call Charges When you end a call, make sure to disconnect the call. If you

Use of the product is not allowed in the

designed to not exceed the limits* of exposure to radio frequency (RF) energy set by governmental authorities. These limits establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by international scientific organizations through periodic and thorough evaluation of scientific studies. The

Tests for SAR are conducted using standardized methods with the phone transmitting at its highest certified power level in all used frequency bands. While there may be differences between meet the relevant guidelines for exposure to radio waves. The highest SAR value as reported to the authorities for this

third-party accessories may result in different SAR levels than those reported. Before a phone model is available for sale to the public in the

Repair and Delivery Support Center (7 days a week/toll free)

The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate (SAR)

UQ mobile Support au Support O Papp/Website App/Website

http://kddi-l.jp/FJ7 (Japanese

URL Chat

For problems on your phone:

ecycle unused telephones, batteries and battery chargers at stores bearing the **(**) logo regardless of brand and manufacturer to protect the

Manufactured by: Sony Corporation

■UQ mobile Support (web) Provides various support information useful for solving your problem. http://kddi-l.jp/DHC
(Japanese)

Al answers you soon all day and our

Mobile phone and PHS operators collect and